



Example of Properly Installed Meter

Meter should be first in-line element after discharge with proper upstream and downstream distance according to manufacturer's specifications.